BSF

DIE CLEVERE WAHL.

PFLEGEANLEITUNG
CARE INSTRUCTIONS

D

Pflegeanleitung

Damit Sie lange Freude an Ihren BSF-Messern haben, lesen Sie bitte vor Benutzung die folgenden Pflegehinweise:

Vor dem ersten Gebrauch

Reinigen Sie Ihre neuen Messer mit warmem Wasser, handelsüblichem Spülmittel und einem weichen Schwamm oder Tuch.

Nach Gebrauch

BSF-Messer (auch mit genieteten Schalen) sollten nicht in der Spülmaschine gereinigt werden, denn hier können zahlreiche Chemikalien zu verstärkter Abnutzung von Klinge und Griff führen.

BSF empfiehlt daher die schonende Reinigung von Hand: Spülen Sie Ihre Messer direkt nach Gebrauch unter fließendem Wasser ab.

Abgetrocknet sind die Messer sofort wieder einsatzbereit. Schneidunterlagen aus Holz oder Kunststoff sind zu bevorzugen.

Schärfen Sie ein BSF Messer mit glatter Schneide z. B. mit einem Messerschärfer von BSF.

www.bsf-trends.com

Achtung: Klingen sind sehr scharf – Verletzungsgefahr!

GB

Care instructions

Please read the following care instructions before using your BSF knives to ensure that you enjoy them for many years to come.

Before using your knife for the first time

Wash your new knife with warm water, a proprietary washing-up liquid and a soft sponge or cloth.

After use

BSF knives (even those with riveted halves) should not be washed in dishwashers. A number of chemicals in your dishwasher can cause increased wear and tear of the blades and handles.

BSF recommends washing your knives by hand as this is gentler to them. Wash your knives immediately after use under running water.

You can use your knives again as soon as they are dry. Preferably use wooden or plastic cutting boards.

Sharpen BSF knives with smooth cutting edges, e. g. with a BSF knife sharpener.

www.bsf-trends.com

Important: Knife blades are very sharp – take care when using as there is a risk of injury!

BSF

DIE CLEVERE WAHL.

A product by ZWILLING International GmbH
Gruenewalder Strasse 14-22
42657 Solingen · Germany
www.zwilling.com | www.bsf-trends.de

01012269Y1_07 17